

PAL-B&G Setting : 01 EU Audio : 5.5MHz

Channel	Frequency(MHz)	Channel	Frequency(MHz)	Channel	Frequency(MHz)
E02	48.25	S24	327.25	38	607.25
E03	55.25	S25	335.25	39	615.25
E04	62.25	S26	343.25	40	623.25
S03	119.25	S27	351.25	41	631.25
S04	126.25	S28	359.25	42	639.25
S05	133.25	S29	367.25	43	647.25
S06	140.25	S30	375.25	44	655.25
S07	147.25	S31	383.25	45	663.25
S08	154.25	S32	391.25	46	671.25
S09	161.25	S33	399.25	47	679.25
S10	168.25	S34	407.25	48	687.25
E05	175.25	S35	415.25	49	695.25
E06	182.25	S36	423.25	50	703.25
E07	189.25	S37	431.25	51	711.25
E08	196.25	S38	439.25	52	719.25
E09	203.25	21	471.25	53	727.25
E10	210.25	22	479.25	54	735.25
E11	217.25	23	487.25	55	743.25
E12	224.25	24	495.25	56	751.25
S11	231.25	25	503.25	57	759.25
S12	238.25	26	511.25	58	767.25
S13	245.25	27	519.25	59	775.25
S14	252.25	28	527.25	60	783.25
S15	259.25	29	535.25	61	791.25
S16	266.25	30	543.25	62	799.25
S17	273.25	31	551.25	63	807.25
S18	280.25	32	559.25	64	815.25
S19	287.25	33	567.25	65	823.25
S20	294.25	34	575.25	66	831.25
S21	303.25	35	583.25	67	839.25
S22	311.25	36	591.25	68	847.25
S23	319.25	37	599.25	69	855.25